

Hanging Instructions

Maya Romanoff Studio designs

Important information

- Check upon receipt that the wallcoverings are as ordered and as specified.
- Check that the wallcoverings are free from damage.
- Make sure that all rolls have the same batch number.
- A final check should be made as to any defects with the wallcoverings before hanging.
- Providing no more than three drops of material are hung we will always replace the wallcovering if it is proven to be faulty. However we will not meet any claims for labour charges or any other damages.
- Any queries must be accompanied by proof of purchase.

Surface Preparation

- Do not hang wallcoverings on to damp walls or wall veneer.
- Prepare the walls by removing all traces of dirt, grease, old wallpaper and loose paint.
- Fill any cracks and allow to dry before hanging any wallcovering.
- Absorbent surfaces should be primed with Murabond primer following the pack instructions carefully.
- Lighter colour wallcoverings will require a surface of a uniform colour.

Adhesive

- Use Murabond Heavy following the pack instructions carefully.

Hanging your wallcoverings

- Measure the length required and cut from the roll, allowing an extra 5mm at the top and bottom of each strip.
- For printed patterns, plan your match from the roll before cutting.
- Number each strip coming from the roll and hang in the same sequence.
- In general Fardis wallcoverings are straight hung, designs that do require reverse hanging will have an appropriate label inserted in the roll.
- Using a roller apply the adhesive evenly to the wall.
- Lay the first strip of wallcovering onto the adhesive film using a spatula in an up and down direction only.
- Continue with the next strip aligning the pattern if required, overlap the strip by 50mm and press both edges to the wall.
- Insert the plastic strip, as supplied, behind the edge of the first wallcovering drop then lay both pieces back flat to the wall.
- Using a sharp snap-blade knife, make a continuous cut from top to bottom through the centre of the overlap, ensuring you cut through both layers. Use a steel straight edge as a guide.
- Remove the plastic strip along with the two waste strips and press the edges down firmly to form a tight joint.
- The plastic strip can then be reused on all joints to complete the job.
- Avoid getting adhesive on the face of the wallcovering as complete removal of adhesive may be impossible.
- Take care not to overwork the joints to prevent any damage.
- Wait 15 minutes before trimming the top and bottom of the drops.

fardis

www.fardis.com

help@fardis.com

+44 (0) 333 240 9045